MASONRY TECHNOLOGY INCORPORATED VITE

MASONRY TECHNOLOGY INC. 24235 ELECTRIC ST, P.O. BOX 214

CRESCO, IA 52136

TOLL FREE: 1-800-879-3348 PHONE: (563) 547-1122 FAX: (563 547-1133

WWW.MTIDRY.COM SURE CAVITY™FABRIC -TO FACE THE WEATHER **EXTERIOR** OF BUILDING FULL STONE VENEER WITH CAVITY SLUSHED **FULL** 10MM SURE CAVITY™ CMU BACKUP WALL (SCMM 2516) APPLY APPROPRIATE AIR STRUCTALATH -AND MOISTURE BARRIER SF CR II AS PER LOCAL CODE AND CLIMATE CONDITION TIE-HVR-195VB ANCHOR SYSTEM BY **HOHMANN & BARNARD** 16" ON CENTER PEEL-AND-STICK FLASHING CUT TO **FOLLOW STONE LINE** AND COVER MORTAR WALL OPENING WEEPS™ (WOW 9095) **HEAVY WATERPROOFING** WALL OPENING WEEPS™ SCORED AND CRACKED OFF WHILE MORTAR IS STILL

NOTES:

PLASTIC

- 1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
- 2. DO NOT SCALE DRAWINGS
- 3. CONTRACTORS NOTE: FOR PRODUCT AND COMPANY INFORMATION VISIT WWW.MTIDRY.COM



FULL STONE VENEER RUN TO GRADE INSTALLATION WITH CMU BACKUP WALL, STRUCTALATH AND H&B STONE WALL TIES

10MM SURE CAVITY™ (SCMM 2516) AND WALL OPENING WEEPS™ (WOW 9095)

MTI CAD drawings are created from sources deemed to be reliable. However, MTI does not guarantee the accuracy or completeness of any information, nor shall be held responsible for any errors, omissions, or damages arising out of the use of this information. These drawings are created with the understanding that MTI is providing information but is not attempting to render engineering or other professional service. If such services are required, the assistance of an appropriate profession should be sought. Use MTI materials in strict conformance with local building codes and regulations. Consult local code/code officials prior to installation. It is the buyer's responsibility to ensure that MTI materials are used in strict conformance with local building codes and regulations.

COPYRIGHT © MASONRY TECHNOLOGY INCORPORATED. 2/17/11. ALL RIGHTS RESERVED

06FR10BW004